




# SuiteConnect 10BaseS Network Access Unit Release Notes

Version 1.00

<http://www.3com.com/>

Part No. DRS10BS-6AAA01  
Published March 2000

---



**3Com Corporation**  
**5400 Bayfront Plaza**  
**Santa Clara, California**  
**95052-8145**

Copyright © 1999, 3Com Corporation. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty, term, or condition of any kind, either implied or expressed, including, but not limited to, the implied warranties, terms or conditions of merchantability, satisfactory quality, and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hard copy documentation, or on the removable media in a directory file named LICENSE.TXT or !LICENSE.TXT. If you are unable to locate a copy, please contact 3Com and a copy will be provided to you.

#### **UNITED STATES GOVERNMENT LEGEND**

*If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:*

All technical data and computer software are commercial in nature and developed solely at private expense. Software is delivered as "Commercial Computer Software" as defined in DFARS 252.227-7014 (June 1995) or as a "commercial item" as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

Portions of this documentation are reproduced in whole or in part with permission from (as appropriate).

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com, the 3Com logo, OfficeConnect, SuperStack, and Transcend are registered trademarks of 3Com Corporation. 3ComFacts is a service mark of 3Com Corporation.

Intel and Pentium are registered trademarks of Intel Corporation. Microsoft, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation in the United States and other countries.

All other company and product names may be trademarks of the respective companies with which they are associated.

Guide written by Ruth Zach and Ronald Schwarz. Edited by Ronald Schwarz and Debbie Zioni. Illustrated by Pearl Goldberg and Ronald Schwarz. Produced by Solectron.

# CONTENTS

Introduction	4
Known Hardware Limitation and Workaround	4
Known Software Limitation and Workaround	6



# SUITECONNECT 10BASES NETWORK ACCESS UNIT RELEASE NOTES VERSION 1.00

---

## Introduction

The SuiteConnect 10BaseS System provides the end user with two main services: fast internet connectivity and fast corporate access. The system works over existing cabling infrastructure and supports all Plain Old Telephone Services (POTS). The system comprises Network Access Unit (NAU) modems and Network Concentration Units (NCU). The NAU and the NCU multiplex voice and data over existing copper cabling. The NAU enables the user to communicate both data and voice over the 10BaseS network while the NCU multiplexes voice and data signals sent to the user and demultiplexes the signals sent from the user.

---

## Known Hardware Limitation and Workaround

### Problem:

Since installing the NAU on the table top does not require fastening the unit, the power connector may loosen and cause the NAU to disconnect and reset.

To avoid this problem, install the NAU using the bracket provided in your installation kit to latch the power supply cord and prevent it from loosening.



Table 1 lists the accessories needed to fit the bracket to the NAU.

**Table 1** NAU Bracket Set


No.	Part	Quantity
1	Bracket	1
2	Cable tie	2

**Workaround:**

- 1 Place the prongs of the latching bracket (Figure 1) into the two holes in the underside of the NAU, shown in Figure 2. Make sure the notches on the neck of the bracket are aligned with the power cord.

**Figure 1** The Latching Bracket**Figure 2** The Underside of the NAU

- 2 Fit the locking cable tie into the notches on the bracket and fasten. Do not fasten tightly. Fasten the tie so that the buckle faces up as shown in Figure 3. The buckle in Figure 3 faces up since the unit is shown up side down.

**Figure 3** Preparing the NAU bottom for Table Top Use

*The bracket edge with the notches must protrude from the unit in parallel with the power cable.*

- 3 Cut the cable tie remaining after the buckle.
- 4 Stick the four rubber pads to the bottom of the NAU as shown in Figure 3.
- 5 Turn the NAU over and place it on top of the table near the ac power and telephone sockets in the room.
- 6 Connect the power cable to the ac power socket in the room.

## Known Software Limitation and Workaround

### Problem:

If a technician frequently disconnects and reconnects the management terminal to the LMI port of the NAU, the NAU loses its synchronization; random characters and symbols appear on the terminal screen.

### Workaround:

- 1 Press ENTER a few times until you receive the following message:

Wrong enter!

The CPE Main Menu reappears on your screen.

- 2 Type any menu selection to check that the unit has been resynchronized. If the selection appears, the unit is synchronized.
- 3 Use the LMI in the normal manner.



*If the problem recurs, repeat steps 1-3.*

---

Copyright © 1999, 3Com Corporation. All rights reserved.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com, SuperStack, and Transcend are registered trademarks of 3Com Corporation.

Other brand and product names may be registered trademarks or trademarks of their respective holders.